

Spill Management**Preparation:**

- Perform glove hygiene in Accel Intervention solution whenever possible glove contamination has occurred, at any point during PPE removal
- Review glove hygiene process:
 - Immerse gloved hands in basin and rub them together in Accel Intervention solution
 - Pat gloves dry with Accel Intervention wipe(s)
- Establish the spill perimeter, and safety during clean up. You may have to plan for a second **Primary+** in the room if visibility during clean-up is a concern (i.e. watching for PPE breaches)
- Create a spill kit, within a plastic bag, in advance of need including the following supplies
 - Absorbent pads (5-10)
 - Hygie or Zorbie® bag inserts – enough to absorb excess spill
 - Accel Intervention solution
 - Extra outer **GREEN** gloves in small plastic bag (minimally 3 pairs); consider more pairs if a large spill
 - Dustpan, banister brush for sharps or broken glass (if present)
 - Red biohazard waste pail with white lid for disposing of sharps, dustpan and banister brush (if glass/sharps present), as indicated above. See images on page 5
- Review how spill should be cleaned; caution when gathering pad inwards, and so on
- Ensure any sharps or broken glass are removed from the spill area using the banister brush and dustpan BEFORE cleaning the spill
- Once sharps removed (if present), explain the cleaning of the spill area is repeated 3 times
 - 1st time to remove gross soil/soak up liquid
 - 2nd time to clean, including all visible soil
 - 3rd time to disinfect spill area
- Notes:
 - Anteroom door is the door between the hallway and anteroom
 - Patient room door is the door between the anteroom and patient room
 - Clean all spilled blood and other body fluids immediately
 - Monitor for gross soiling of PPE throughout the process
 - Optional sections for soiled vs non-soiled gloves or gross soiling in basin instructions in sections 5, 6 and 7
 - If at any point in the process the **Primary+** has soiled scrubs, proceed to the Soiled Scrubs Checklist

Spill Management

Legend

Primary+
Monitor ♣
Assistant 1Ω

Process:

1. Primary+ in patient room
Assistant 1Ω
PREPARATION
Gather appropriate supplies and place in a plastic bag. <i>See preparation</i>
Don Assistant 1Ω PPE
Enter anteroom with supplies and pass them to Primary+
After Primary+ re-enters room, Assistant 1Ω to doff PPE as per doffing checklist

Primary+ NOT in patient room
Primary+
PREPARATION
Gather appropriate supplies and place in a plastic bag. <i>See preparation</i>
Don Primary+ PPE
Enter anteroom and wait for anteroom door to close
Enter patient room with supplies. Go to section 3

2. IF PRIMARY+ IN PATIENT ROOM AT TIME OF SPILL PRIMARY+ RECEIVES SUPPLIES
Primary+
Perform glove hygiene
Wipe door handle and door plate with Accel Intervention wipe. Discard wipe and allow 1-minute wet contact time
Wipe supply cart work top with Accel Intervention wipe. Discard wipe and allow 1-minute wet contact time
Open patient room door and step onto the disinfectant mat on the Primary+ side
Perform glove hygiene
Receive supplies from the Assistant 1Ω
Re-enter patient room

3. Primary+	Considerations
If a red biohazard waste pail brought in for glass/sharps removal, place pail down on the floor near blue drum, remove the lid from the pail	Use top of supply cart for placement of supplies in room
Organize supplies on a clean work surface	
Ensure the extra outer GREEN gloves are easily accessible while still protected in plastic bag	
Organize room so the Primary+ can clean the spill while being visualized by Monitor ♣	
Ensure blue drum can accommodate all spill waste	

Spill Management

4. Primary+	Considerations
REMOVAL OF GLASS/SHARPS FROM SPILL AREA	
<p>Check for broken glass/sharps If present: Ensure red biohazard waste pail is open</p>	<p>** IF no glass/sharps present proceed to section 5</p> <p>A significant amount of pressure pushing down on rim of lid is required to secure lid on red biohazard waste pail</p>
Use banister brush and carefully sweep glass/sharps into dustpan	
Discard ALL (banister brush and dustpan with contents) into the red biohazard waste pail	
Secure white lid on the red biohazard waste pail by pushing down hard on the rim with palms of hands, working around the entire rim	
Place red biohazard waste pail in blue drum	
Perform glove hygiene	

5. Primary+	Considerations
CONTAIN SPILL AREA AND REMOVE GROSS SOIL/SOAK UP LIQUID	
Cover spill from outside-in with Zorbi® bag inserts	<p>Establish a spill perimeter (contain the spill; immediately put absorbent pads around it, as appropriate)</p>
Layer absorbent pads on top of Zorbi® bag inserts, layering from outside-in	
Working from outside-in, pick up as much of the spill as possible	
Remove and discard soiled Zorbi® bag inserts and absorbent pads in blue drum after spill soaked up	
Repeat as needed until the entire spill has been absorbed	
<p>Check gloves for visible soiling:</p> <ul style="list-style-type: none"> • If NOT soiled: perform glove hygiene • If SOILED <ul style="list-style-type: none"> ○ Wipe gloves with Accel Intervention/AHP wipe to remove soiling ○ Perform glove hygiene ○ Remove outer GREEN gloves with caution; discard into blue drum ○ Perform glove hygiene on inner BLUE gloves ○ Apply new outer GREEN gloves 	<p>Avoid touching self or contaminating self with absorbent pads or liquid</p> <p>Check glove hygiene basin for visible soiling. If soiled go to section 7</p>

Spill Management

6. Primary+	Considerations
<p>CLEAN SPILL AREA, INCLUDING ALL VISIBLE SOIL</p> <p>Cover spill area with an absorbent pad</p> <p>Soak absorbent pad in Accel Intervention solution</p> <p>Wipe spill area from outside toward center using soaked absorbent pads</p> <p>Discard the soiled absorbent pads in blue drum</p> <p>Check gloves for visible soiling:</p> <ul style="list-style-type: none"> • If NOT soiled: perform glove hygiene • If SOILED <ul style="list-style-type: none"> ○ Wipe gloves with Accel Intervention wipe to remove soiling ○ Wipe AHP tub with new Accel Intervention wipe ○ Perform glove hygiene ○ Remove outer GREEN gloves with caution; discard into blue drum ○ Perform glove hygiene on inner BLUE gloves ○ Apply new outer GREEN gloves 	<p>DO NOT splash or spray disinfectant</p> <p>Avoid touching yourself or contaminating yourself with pads or liquid</p> <p>Ensure clean outer GREEN gloves for disinfection step</p> <p>Check glove hygiene basin for visible soiling. If soiled go to section 7</p>

7. Primary+	Considerations
<p>CHECK FOR ANY VISIBLE SOIL AND/OR DEBRIS IN BASIN CONTAINING ACCEL INTERVENTION SOLUTION. IF PRESENT:</p> <p>Pour Accel Intervention solution from glove hygiene basin into toilet</p> <p>Wipe basin with Accel Intervention wipe</p> <p>Allow 1-minute wet contact time</p> <p>Refill basin with Accel Intervention solution</p> <p>Perform glove hygiene</p>	<p>Ensure glove hygiene basin is clean before moving on to disinfection step</p>

8. Primary+	Considerations
<p>DISINFECT SPILL AREA</p> <p>Cover spill area again with absorbent pads</p> <p>Soak absorbent pads in Accel Intervention solution</p> <p>Allow absorbent pads to soak for a minimum of 10 minutes</p> <p>Push soaked absorbent pads from the outside towards the center</p> <p>Discard the absorbent pads in blue drum</p>	<p>Assess disinfectant area.</p> <p>Place dry absorbent pad on any damp areas</p>

Spill Management

9. Primary+	Considerations
CHECK GLOVES FOR VISIBLE SOILING	
<p>Check gloves for visible soiling:</p> <ul style="list-style-type: none"> • If NOT soiled: perform glove hygiene • If SOILED <ul style="list-style-type: none"> ○ Wipe gloves with Accel Intervention/AHP wipe to remove soiling ○ Perform glove hygiene ○ Remove outer GREEN gloves with caution; discard into blue drum ○ Perform glove hygiene on inner BLUE gloves ○ Apply new outer GREEN gloves 	<p>Check glove hygiene basin for visible soiling. If soiled go to section 7</p>

10. Primary+	Considerations
CHECK PPE FOR SOILING	
<p>If SOILED PPE:</p> <p>Remove gross soiling from PPE with Accel Intervention/AHP wipes and dispose in blue drum</p> <p>Perform glove hygiene</p> <p>Remove outer GREEN gloves with caution; discard into blue drum</p> <p>Perform glove hygiene on inner BLUE gloves</p> <p>Apply new outer GREEN gloves</p>	<p>Check glove hygiene basin for visible soiling. If soiled go to section 7</p>
<p>If Primary+ has gross soiling of PPE, proceed to doffing checklist to change out soiled PPE</p> <p>If there is NO soiling of PPE and the Primary+ is okay to continue on, proceed immediately to the Waste Removal checklist</p> <p>Record the incident using the High Consequence Pathogen Incident Log</p>	

Banister Brush and Dustpan



Red Biohazard Pail with Lid

To secure lid on pail: push down on rim with palms of your hands, working around entire rim. A significant amount of pressure pushing down is required to snap the lid on.

